

ACCESSORIES




Cordless Speedee Trim Battery Charger

Cordless battery and charger provides 80 minutes of run time for a 2 hour charge.

Blade Scrubber

Nylon bristle blade scrubber cleans blades in seconds. Keeping the unused blade in the scrubber filled to 3/4 capacity with isopropyl alcohol will insure for a quick swap out with the dirty blade and continued trimming.



www.SpeedeeTrim.com